

## Installation Instructions – PM262

## SL244 / SLGL254 Spot-LIGHTZ (4.5W)

### Mounting:

SL244 Surface mount

SLGL254 Spike mount 2

### Constant current:

500mA (max)

### Caution:

Always turn power off when connecting or disconnecting luminaires.  
All cabling connections required to be fully waterproofed for exterior installation.

### Warranty:

**Luminaire:** 5 years

Warranty will be void if the product is immersed fully in water.

All cabling connections are required to be fully waterproofed.

Proof of purchase is required. See website for full warranty conditions.

### How many constant current lights per driver?

Click on the QR code to check max & min number of lights to connect and dimmer information.:

or visit

[www.switch-lighting.co.nz/](http://www.switch-lighting.co.nz/)

Library / Tips and Tricks



### Installation:

(by registered electrician only)

1. Ensure driver is disconnected from mains supply before connecting LED/s.
2. Connect the LED/s and driver in **SERIES**.
3. Ensure connections are watertight – LED/s and driver may be permanently damaged if not wired correctly.
4. Switch off LED driver and wait 5 seconds before making any change to secondary circuit (eg. replacing LED).

